Customer Service



Field Service Note

T9030/31/40 Teac Floppy Disk Drives Jumper Settings August 20, 1997 SN90x0.011

Subject: There are two different types of Teac floppy disk drives. Listed below are the jumper settings for the Teac FD 232HG and HF versions.

Teac FD-235HG

| DRIVE A | | | | | DRIVE B | | | | |
|---------|---|---|-----|---|---------|---|---|---|----|
| FG | Н | * | * | | F G | Н | * | * | |
| | G | * | * | * | | G | * | * | * |
| | F | * | * | * | | F | * | * | * |
| | E | * | T T | * | | E | * | * | * |
| J2 | D | * | * | * | Ј2 | D | * | * | * |
| | C | * | * | * | | C | * | * | 77 |
| | В | | * | ক | | В | | * | * |
| | A | | * | * | | A | | * | |
| | | 3 | 2 | 1 | | | 3 | 2 | 1 |

Teac FD-235HF

| DRIVE A | | | | | | DRI | VE B | | | | |
|---------|--------|-----|----|---|---|-----|--------|---|---|---|----|
| FG | G F | * | * | * | * | FG | G F | * | * | * | * |
| | Е | is- | ** | * | * | | E | * | * | * | * |
| J2 | D | * | * | * | * | J2 | D | * | * | * | * |
| | C | * | * | * | * | | C | * | * | * | 75 |
| | В | r | ſ | * | ſ | | В | 6 | 6 | * | * |
| | A | * | * | * | * | | A | * | * | * | * |
| | | 4 | 3 | 2 | 1 | | | 4 | 3 | 2 | 1 |
| | | | | | | | | | | | |